

PD HS Midwest Tradition-PB Instructions for Installation
Turbine Assembly P/N 23069

v01



1 Place blue o-rings onto front and rear bearings of TA



2 Insert turbine assembly into head housing



3 Screw on back cap, refer to section 5 of the TA Installation Procedure

