## PD HS Midwest Tradition-L Instructions for Installation Turbine Assembly P/N 23067





1 Place black o-ring into back cap



3 Insert turbine assembly into head housing



2 Place blue o-ring on front bearing of turbine assembly



**4** Screw on back cap, refer to section 5 of the TA Installation Procedure



