

For best results, always use NoCord VPS Wash Material with NoCord VPS MegaBody Tray Material.

Centrix[®] Making Dentistry Easier.^{®#}

Visit www.CentrixNoCordVPS.com

QUICK START GUIDE

NoCord[™] VPS

MegaBody[™] 380 Tray Material



Remove cap.



Insert cartridge in Automix Machine. Bleed cartridge.



Attach SuperMix™ Mixing Tip, 380 Yellow to cartridge.



Twist on Yellow Bayonet Ring.



Syringe NoCord VPS™ Wash onto prep. Generously cover prep and adjacent teeth.



Express MegaBody[™] fully loading tray. Seat tray over unset Wash Material. Apply firm pressure or have patient bite firmly.



Set timer for 4:45. Create 'time check beads' of NoCord VPS™ Wash & MegaBody!™



Remove impression from mouth at **4:45**. Inspect impression.

Photos 6 & 8 courtesy of Dr. Miguel A. Ortiz DDS, Brookline, MA

*Always apply Access® VPS Tray Adhesive to selected tray.

REF 310286 NoCord VPS[™] MegaBody[™] 380 Tray Material, 1-pk REF 310287 NoCord VPS[™] MegaBody[™] 380 Tray Material, 2-pk REF 910637 SuperMixer[™] Mixing Tips, 380 Yellow 40-pk REF 910631 SuperMixer [™] Mixing Tips, Yellow with 18 ga tip pk, 50-pk REF 910638 Bayonet Ring, Yellow 2-pk REF 310282 NoCord VPS[™] Wash, Material, 2-pk REF 310284 NoCord VPS[™] Wash, Material, 10-pk REF 360005 Access* VPS Tray Adhesive





For additional information, clinical video, tips and doctors testimonials, visit www.CentrixNoCordVPS.com