



By: TORIADO  
PLASTICS Inc.

# INTRAORAL SHEATHS

"The Clear Choice"



## TIPP INTRAORAL CAMERA BARRIER SOLUTIONS (IOC) 6 STYLES

ALWAYS UPDATED TO FIT THE NEWEST AND MOST POPULAR CAMERA BRANDS

TIPP ITEM#	CUST. ITEM #	DESCRIPTION	Qty/Box			
<b>IOC100</b>	<b>07-110-7333</b>	5" model length	QTY 100 /BOX			
FITS BRAND MODEL	SIRONA SIROCAM-3	GENDEX C300	RF AMERICA IDS FOCUS	RF AMERICA IDS DR. CAM	RF AMERICA IDS EZ SHOT	RF AMERICA IDS DISCOVERY 360
	XDR RADIOLOGY XDR & SUNI	SOREDEX DIGORA VIDI	DURR DENTAL VISTACAM IX	MOUTHWATCH	ACTEON SOPRO 617	
<b>IOC200</b>	<b>07-083-6304</b>	5" model length	QTY 100 /BOX			
FITS BRAND MODEL	ACTEON SOPRO717	ACTEON SOPRO LIFE	ACTEON SOPRO CARE	IRIS DIGI DOC	IRIS 2.0	
<b>IOC400-600</b>	<b>07-110-7358</b>	5" model length	QTY 100 /BOX			
FITS BRAND MODEL	MY RAY C-U2	SCHICK USB #1 #2 #8	NDI DOCPORT	KODAK CARESTREAM 1500	KODAK CARESTREAM 1600	3M MESPE SCANNER TRUE DEFINITION
	POLAROID HD					
<b>IOC700</b>	<b>07-110-7374</b>	5" model length	QTY 100 /BOX			
FITS BRAND MODEL	SIRONA SIROCAM AF	SIRONA SIROCAM AF+	KAVO ERGOCAM S			
<b>IOC800</b>	<b>07-110-7382</b>	8.25" model length	QTY 100 /BOX			
FITS BRAND MODEL	DEXIS DEKCAM #4	DURR DENTAL VISTACAM CLIK IX	IRIS DIGIDOC #1 LTE	IRIS HD 3.0		
	AIR TECHNIQUES CAM X LLUNA	AIR TECHNIQUES SPECTRA (G4000)	AIR TECHNIQUES CAM X TRITON	AIR TECHNIQUES POLARIS		
<b>IOC900</b>	<b>07-110-7390</b>	7.5" model length	QTY 100 /BOX			
FITS BRAND MODEL	KODAK CARESTREAM 1200	AIR TECHNIQUES CAM X SPECTRA J2300	AIR TECHNIQUES CAM X ELARA	DEXIS DEKCAM #3		

### FEATURES & BENEFITS

ALWAYS UPDATED FOR USE ON A VARIETY OF MOST POPULAR INTRAORAL CAMERAS  
 SUPER CLEAR MATERIAL EXCEPTIONAL CLARITY  
 EASILY ADJUSTABLE FITTED TIP ELIMINATES AIR POCKETS & IMAGE DISTORTION  
 SPECIFICALLY DESIGNED FOR SEAMLESS LENS CONTACT  
 SOFT-TOUCH MATERIAL DESIGNED FOR PATIENT COMFORT  
 PATENTED MATERIAL COMBINATION FOR EFFORTLESS POSITIONING  
 EASY TEAR-AWAY REMOVAL AVOIDS STICKING TO LENS & DAMAGING EQUIPMENT  
 LATEX-FREE FOR NO UNPLEASANT FLAVOUR  
 INTERLEAFED DISPENSER PACKAGING TO AVOIDS CROSS CONTAMINATION



### CAMERA BARRIER INSERTION AND TEAR-AWAY REMOVAL INSTRUCTIONS

#### EASY INSERTION



#### TEAR-AWAY REMOVAL



- 1) While holding the bottom of sheath and paper, open and insert camera under frosted layer with lens facing paper.
- 2) Gently slide camera into sheath until tip is snugly positioned at the end of sheath.
- 3) DO NOT FORCE. If product becomes torn or punctured do not use.
- 4) Once properly positioned, detach from paper. Camera is now ready to use.
- 5) Once treatment completed, tear-away frosted layer from clear and immediately discard both.