



**1** Place o-ring into back cap



**2** Place o-ring into head housing



**3** Insert turbine assembly into head housing



**4** Screw on back cap, refer to section 5 of the TA Installation Procedure

