



1 Place o-ring into back cap




2 Place o-ring into head housing



3 Insert turbine assembly into head housing



4 Screw on back cap, refer to section 5 of the TA Installation Procedure



Back Cap Tool

ProDrive Back Cap

Back Cap O-ring

Turbine Assembly

Head O-ring

Head Housing